A sharing feature has been included in **PIPECLASS3**.

From the main screen click on ‘Share’.



In the pop up add the email of who you want to share with.

To share the user must be a registered user of **PIPECLASS3.** If they are not a registered user, you can only send them a PDF of the design that you have saved on your own device.



Simply add the email address, click 'Share' and the user you have shared with will receive an email advising them that you have shared a design.



Fwd: Pipe Class v3.0.0 - Design shared

KT Karen Thompson <kt.concretegirl@gmail.com>
To Karen Thompson

---------- Forwarded message ---------
From: <pipeclass@genolis.com.au>
Date: Thu, 16 May 2024 at 3:31 PM
Subject: Pipe Class v3.0.0 - Design shared
To: <kt.concretegirl@gmail.com>

Hello Karen Thompson,

karen thompson has shared Design 1 design with you. Use the link below to view the design

https://cpaaa.uniconsoftware.com.au/edit/27

Pipe Class v.3.0.0

They simply click on the link and it takes them to **PIPECLASS3**. When they sign in the shared design will automatically open.

Designs are accessed from the drop down under your user name.





You can open or copy the design by clicking on the dots to the left of the design.



With a shared design the 'Save as Copy' is used instead of 'Save' to ensure you don't edit someone else's design but enables you to perform the same design and change parameters with file name version control.